



| # | DESCRIPTION | PART NUMBER | QTY |
|----|---|--------------|-----|
| 1 | Tubo elimina kat / No kat pipe | 9773D033C1A | 1 |
| 2 | Tubo elimina kat / No kat pipe | 9773D033C1B | 1 |
| 3 | Tubo elimina kat / No kat pipe | 9773D033C1C | 1 |
| 4 | Tubo elimina kat / No kat pipe | 9773D033C1D | 1 |
| 5 | Silenziatore / Muffler - db killer 50.DK.075.0 | SUONO 270 | 1 |
| 6 | Tassello grande / Rubber big block | 50.73.203.1 | 2 |
| 7 | Tassello piccolo / Rubber small block | 50.73.202.1 | 2 |
| 8 | Vite M8x25 / Screw M8x25 | 50.73.064.1 | 1 |
| 9 | Rondella in alluminio nera / Black aluminium washer | 50.73.221.1 | 1 |
| 10 | Rondella in gomma / Rubber washer | 50.73.227.1 | 1 |
| 11 | Staffa in carbonio / Carbon fiber bracket | 50.SS.180.1 | 1 |
| 12 | Staffa / bracket | 50.SS.952.0 | 1 |
| 13 | Dado M8 flangiato / Flanged nut M8 | 50.73.393.1 | 1 |
| 14 | Vite M6 x 20 / Screw M6 x 20 | 50.73.422.1 | 1 |
| 15 | Rondella M6 / Washer M6 | 50.73.187.1 | 2 |
| 16 | Dado M6 autobloccante / M6 locknut | 50.73.112.1 | 2 |
| 17 | Fascetta Ø 56/59 mm / Pipe clamp Ø 56/59 mm | 50.FA.009.1 | 1 |
| 18 | Vite M6x35 / Screw M6x35 | 50.73.228.1 | 1 |
| 19 | Rondella alluminio / Aluminium washer | 50.73.349.1 | 1 |
| 20 | Fascetta passacavi / Fairlead clamp | 50.73.796.0 | 1 |
| 21 | Molla / Spring | 50.73.142.1 | 1 |
| 22 | Grani M3 / Grub screws M3 | 50.73.140.1 | 2 |
| 23 | Morsetti in alluminio / Aluminium clamps | 50.73.138.1 | 1 |
| 24 | Tubo in gomma per molla / Rubber pipe for spring | 50.73.210.1 | 5 |
| 25 | Molla lunga / Long spring | 50.71.080.1 | 4 |
| 26 | Molla media / Mid-size spring | 50.73.359.1 | 1 |
| 27 | Vite M5 x 8 / Screw M5 x 8 | 50.73.233.1 | 3 |
| 28 | Rondella M5 / Washer M5 | 50.73.351.1 | 3 |
| 29 | Cover in carbonio / carbon cover | 50.CR.030.1 | 1 |
| 30 | Dado rapido M5 / M5 cage nut | 50.73.674.1 | 3 |
| 31 | Staffa / Bracket | 50.73.1122.0 | 3 |
| 32 | Fascetta / Clamp | 50.73.795.1 | 3 |

Assemblaggio cavo della valvola a farfalla:

- 1) Estrarre il cavo della valvola a farfalla dalla sua sede.
- 2) Prendere la molla e inserire le prime spire sul cavo d'acciaio di comando della valvola a farfalla.
- 3) Ruotando la molla, essa si avvolgera' completamente al cavo d'acciaio.
- 4) Quando la molla e' ben inserita sul cavo d'acciaio montare il distanziale per fine corsa valvola e serrare i grani.
- 5) Fissare il cavo sulla fascetta 50.73.796.0.

Throttle cable assembly:

- 1) Remove the throttle cable from its seat.
- 2) Take the spring and enter the first coil on the steel cable throttle valve control.
- 3) Turning the spring, it will completely wrap the steel cable.
- 4) When the spring is correctly mounted on the steel cable, assemble the aluminium clamp and tighten the grub screws.
- 5) Secure the cable with the 50.73.796.0 clamp.

| APPLICAZIONI / APPLICATIONS | | | |
|-----------------------------|------------------------|------------------|-------------------------|
| CODICE / CODE | SILENZIATORE / MUFFLER | TUBO / PIPE | FASCETTA / CLAMP |
| D.033.S9 | STEEL BLACK | INOX / ST. STEEL | CARBONIO / CARBON FIBER |

